



O₂ sensor configuration settings

The following table shows the configurable items that can be changed in the Sensor software menus.

 **NOTE:** PLEASE MAKE A NOTE OF THE NEW CONFIGURATION SETTING IN THE NEW SETTING COLUMN NEXT TO EACH CONFIGURATION OPTION.

Item	Default setting	New setting	Comment
Alarm One Enabled	FALSE		Enable alarm
Alarm One Set-point	19.50%		Threshold for the alarm
Alarm One Direction	Low Going		Can be set to either low going or high going
Alarm One Strobe Enable	FALSE		Activates the strobe on alarm
Alarm One Sounder Enable	FALSE		Activates the sounder on alarm
Alarm One Evacuation Enabled	FALSE		Activates the strobe and sounder of connected sensors on alarm
Alarm One Latching Enable	TRUE		Requires the user to mute and acknowledge the alarm before the alarm will clear
Alarm Two Enabled	TRUE		Enable alarm
Alarm Two Set-point	19.50%		Threshold for the alarm
Alarm Two Direction	Low Going		Can be set to either low going or high going
Alarm Two Strobe Enable	TRUE		Activates the strobe on alarm
Alarm Two Sounder Enable	FALSE		Activates the sounder on alarm
Alarm Two Evacuation Enabled	FALSE		Activates the strobe and sounder of connected sensors on alarm
Alarm Two Latching Enable	TRUE		Requires the user to mute and acknowledge the alarm before the alarm will clear
Alarm Three Enabled	TRUE		Enable alarm
Alarm Three Set-point	23.00%		Threshold for the alarm
Alarm Three Direction	High Going		Can be set to either low going or high going
Alarm Three Strobe Enable	TRUE		Activates the strobe on alarm
Alarm Three Sounder Enable	TRUE		Activates the sounder on alarm
Alarm Three Evacuation Enabled	FALSE		Activates the strobe and sounder of connected sensors on alarm

Ax60+ O2 Sensor Configuration Sheet

Int. Approved

Item	Default setting	New setting	Comment
Alarm Three Latching Enable	TRUE		Requires the user to mute and acknowledge the alarm before the alarm will clear
Alarm Four Enabled	TRUE		Enable alarm
Alarm Four Set-point	18.00%		Threshold for the alarm
Alarm Four Direction	Low Going		Can be set to either low going or high going
Alarm Four Strobe Enable	TRUE		Activates the strobe on alarm
Alarm Four Sounder Enable	TRUE		Activates the sounder on alarm
Alarm Four Evacuation Enabled	FALSE		Activates the strobe and sounder of connected sensors on alarm
Alarm Four Latching Enable	TRUE		Requires the user to mute and acknowledge the alarm before the alarm will clear